



LL-HD05R

Haisen HD05R Remote Control

BUTTON LAYOUT			
Button	Description	Button	Description
ON/OFF	Switch ON/OFF the light; Switch OFF the sensor function.	MW/PIR	Mode Switch
Reset	Switch to sensor mode and reset all settings to factory defaults: (Detection area-100%, Hold time-5s, Daylight- Disable, Standby Period-0s, Standby Dimming Level-10%)	Start	Press the key to start setting parameters with memory and apply functions in sensor mode. <ul style="list-style-type: none"> Press "Start". The letter "S" will flash in the lower-left corner of the display, indicating parameter setup has begun. After setting all parameters, press "Memory" to store the settings. These will remain until the next reset. Press "Apply" to send the stored settings to the sensor within the remote IR range. Note: All data shown on the display reflect the settings after pressing "Memory".
Detection Area	Under sensor mode, press the key. The icon on the display will flash. Press "+" / "-" to select sensitivity.	Memory	
Daylight Threshold	Under sensor mode, press the key. The icon on the display will flash. Press "+" / "-" to select the daylight threshold.	Apply	
Hold Time	Under sensor mode, press the key. The icon on the display will flash. Press "+" / "-" to select the hold time. <ul style="list-style-type: none"> HD06VCRH 7B2: 5s/30s/1min/3min/5min/10min/20min/30min HD015VCRH: 5s/30s/1min/3min/5min/10min/20min/30min HB001 VCR 1: 10s/1min/5min/10min HB002VCR: 5s/30s/1min/3min/5min/10min/20min/30min 	Standby Period	Under sensor mode, press the key. The icon on the display will flash. Press "+" / "-" to select the low brightness time. <ul style="list-style-type: none"> HD06VCRH 7B2: 0s/10s/30s/1min/5min/10min/30min/60min+∞ HD015VCRH: 0s/10s/30s/1min/5min/10min/30min/+∞ HB001 VCR 1: 1min/30min/60min/+∞ HB002VCR: 0s/10s/30s/1min/5min/10min/30min/60min/+∞
Standby Dimming Level	Under sensor mode, press the key. The icon on the display will flash. Press "+" / "-" to select the low brightness during standby period.	Test Mode	Press the key to enter test mode under sensor mode. The settings will not be saved after power OFF. Test mode parameters: Detection Area-100%, Hold Time-2s, Daylight-disable, Standby Period-0s, Standby Dimming Level-10%.
UP	After selecting a parameter, press either key to adjust (UP/DOWN) the required setting.	POWER	Under sensor mode, press "POWER". "PW" will flash on the middle-left of the display. Use "+" / "-" to adjust the output power.
DOWN			

NOTE: Press "Scene" to reset the remote before using. During the setting of each parameter, the icon will flash for 5s. After that, the setting will be kept automatically.



HD05R REMOTE CONTROL PROCEDURE

Microwave Motion Sensor Settings - One Sensor

1. Press "ON/OFF" to turn on the light.
2. Press "Scene" to reset the remote and switch to sensor mode.
3. Press related keys to set detection area, hold time, daylight threshold, standby period and standby dimming level. When the icon starts to flash, press "+" / "-" within 5s to adjust the settings.
4. All settings will be saved automatically until the next reset.

Start / Memory / Apply - Applied to Multiple Sensors

1. Press "ON/OFF" to turn on the light.
2. Press "Scene" to enter sensor mode. Then press "Start" to start the user-defined setting.
3. Press related keys to set detection area, hold time, daylight threshold, standby period and standby dimming level. When the icon starts to flash, press "+" / "-" within 5s to adjust the settings.
4. Press "Memory" to store the setting.
5. Press "Apply" to all sensor within remote IR range. The light will blink rapidly when receiving the signal, meaning the sensor has been set successfully.

Power Output Setting

1. The output could be set under two mode-Sensor Mode and Always ON Mode.
2. Under always ON mode, press "+" / "-" to adjust the output from 10%~100%.
3. Under the sensor mode, press "Scene" - "Power", then press "+" / "-" to adjust the output from 60%~100%.

NOTE: Under the sensor mode, the displayed setting range is 10%–100%. However, the minimum brightness is 60% and will not dim below this level.



Haisen HD05R Remote Control

PROJECT NAME	
CATALOG #	
JOB TYPE	
PREPARED BY	
NOTES	

ORDERING INFORMATION

Part #	Description
HD05R	Haisen HD05R Remote Control